




# eurow style™

## Assembly Instructions

Eileen Gray



**PLEASE NOTE:** Check that you have received all components and hardware before assembling. If you are missing any parts, contact your retailer, or fax Euro Style at 415-455-8033.



During assembly, **hand tighten** screws only. When all screws are in place, then tighten them completely.