


Thank you for purchasing the MODWAY DINING CHAIR!


Before you start, here is some helpful advice:

- 1. We suggest you spend a short time reading through this leaflet and then follow the simple step-by-step instructions.
- 2. Owing to the size and weight of the dining chair, we recommend that it is assembled by two adults, on a carpeted or padded area, in the room that it is intended for. Approximate assembly time: 30 minutes.
- 3. Please do not use any tools other than those provided or recommended in these instructions.
- 4. Please do not throw away any of the packaging or instructions until you have checked all the components and hardware and the furniture is fully assembled.
- 5. Assemble all components loosely until advised to tighten. Depending on use, it may be necessary to tighten the components from time to time, so please save the tools that have been provided.
- 6. Please keep all pieces out of reach of children.



Component:

1 Chair Back



×1

x2

Front Leg

3




STEP1: Please open the Velcro on the bottom of Chair Seat (2).

Insert 1 piece of Front Leg (3) into the bottom of Chair Seat (2) as shown.

Attach by 2 pieces of **Bolt (A)**, 2 pieces of **Spring Washer (B)**, and 2 pieces of **Flat Washer (C)** as shown.

Repeat the same steps for another Front Leg (3).


Do not fully tighten Bolts (A) for either leg.



STEP2: Please put Chair Back (1) upside down on a carpeted or padded area.

Then attach Chair Seat (2) to Chair Back (1) by using 2 pieces of Bolt (A), 2 pieces of Spring Washer (B), and 2 pieces of Flat Washer (C) for each corner as shown.

Do not fully tighten all Bolts (A).



9)1111111111111111111111111111111111111			
A×4	B×4	C×4	D×1


Hardware & Tool required



STEP3: Carefully turn over the chair.

Please put a heavy object or seat one adult on top of the **Chair Seat (2)** to pressure the chair for leveling.


Fully tighten all Bolts (A) with Allen Wrench (D).




D×1

Hardware & Tool required

STEP4: Recover the Velcro on the bottom of Chair Seat (2).





Hardware & Tool required