


























Thank you for purchasing the **MODWAY SIDEBORD** !

Before you start, here are some helpful advice:


1. We suggest you spend a short time reading through this leaflet and then follow the simple step-by-step instructions.
2. Owing to the size and weight of the Sideboard, we recommend that it is assembled by two adults, on a carpeted or padded area, in the room that it is intended for. Approximate assembly time: 60 minutes.
3. Please do not use any tools other than those provided or recommended in these instructions.
4. Please do not throw away any of the packaging or instructions until you have checked all the components and hardware and the furniture is fully assembled.
5. Assemble all components loosely until advised to tighten. Depending on use, it may be necessary to tighten the components from time to time, so please save the tools that have been provided.
6. Please keep all pieces out of reach of children.



## Hardware :


<b>A)</b> Cambolt/Metal  $\varnothing 6 \times 35 \text{ mm}$ x 26	<b>B)</b> CamLock Big/Metal  $\varnothing 15 \text{ mm}$ x 26	<b>C)</b> Dowel Medium/Wood  $\varnothing 8 \times 30 \text{ mm}$ x 50	<b>D)</b> Screw/Metal  $M 7 \times 50 \text{ mm}$ x 6	<b>E)</b> Shelf Pin/Metal  $\varnothing 5 \times 15 \text{ mm}$ x 24
<b>F)</b> Screw/Metal  $M 6.4 \times 14 \text{ mm}$ x 12	<b>G)</b> Key/Metal  $L 4$ x 1	<b>H)</b> Screw/Metal  $M 3.5 \times 15.5 \text{ mm}$ x 20	<b>I)</b> Wedge/Plastic  $9 \times 14 \times 10 \text{ mm}$ x 20	<b>J)</b> Sliding Door Plate/Metal, Plastic  $135 \times 35 \times 28 \text{ mm}$ x 4
<b>K)</b> Iron Plate/Metal  $1625 \times 25 \times 3 \text{ mm}$ x 1	<b>L)</b> Screw/Metal  $M 6.4 \times 25 \text{ mm}$ x 20	<b>M)</b> Hinge/Metal  $83 \times 53 \times 27 \text{ mm}$ x 4	<b>N)</b> Screw/Metal  $M 3.5 \times 13 \text{ mm}$ x 8	
<b>O)</b> Screw/Metal  $M 6 \times 12.5 \text{ mm}$ x 8	<b>P)</b> Handle/Metal  $\varnothing 40 \text{ mm}$ x 2	<b>Q)</b> Screw/Metal  $M 4 \times 20 \text{ mm}$ x 2	<b>R)</b> Dowel Large/Wood  $\varnothing 8 \times 50 \text{ mm}$ x 2	<b>S)</b> Iron Plate/Metal  $1625 \times 25 \times 3 \text{ mm}$ x 2
<b>T)</b> Dowel Small/Wood  $\varnothing 8 \times 20 \text{ mm}$ x 8	<b>U)</b> Foam Pad/Spon  $25 \times 50 \times 2 \text{ mm}$ x 4	<b>V)</b> Buffer/Rubber  $\varnothing 8 \text{ mm}$ x 4	<b>W)</b> Stopper/Plastic  $\varnothing 9 \times 21.5 \text{ mm}$ x 2	<b>X)</b> Screwdriver (Not Include)  x 1

## Components:




1	Top Board	x1	2	Bottom Board	x1	3	Leg Left Front	x1	4	Leg Left Back	x1
5	Leg Right Front	x1	6	Leg Right Back	x1	7	Side Board Left	x1	8	Side Board Right	x1
9	Centre Board Left	x1	10	Centre Board Right	x1	11	Adjustable Shelf 1	x2	12	Adjustable Shelf 2	x4
13	Front Skirt 1	x1	14	Bottom Skirt	x1	15	Support Board 1	x2	16	Wooden Door 1	x2
17	Handle	x4	18	Back Board 1	x2	19	Back Board 2	x2	20	Leg Middle	x2
21	Front Skirt 2	x1	22	Mesh Door L	x1	23	Mesh Door R	x1			


## STEP 1:



## STEP 2:




## STEP 3:



Cx8	Mx4	Ox8	Tx8	Xx1

Hardware required.  
Screwdriver not included


## STEP 4:





Dx2	Gx1

Hardware required.


## STEP 5:





	
Bx4	Xx1

Hardware required.  
Screwdriver not included


## STEP 6:




	
Bx4	Xx1

Hardware required.  
Screwdriver not included


## STEP 7:



## STEP 8:




## STEP 9:



G	Fx4	Rx2	Sx2

Hardware required.


## STEP 10:





Bx2	Xx1

Hardware required.  
Screwdriver not included


## STEP 11:






	
Ax8	Xx1

Hardware required.  
Screwdriver not included

## STEP 12:





		
Bx8	Ux4	Xx1

Hardware required.  
Screwdriver not included





## STEP 13:




Hardware required.

## STEP 14:







Hardware required.

## STEP 15:




## STEP 16:





		
G	Kx1	Lx6

Hardware required.


## STEP 17:





	
Cx4	Wx2

Hardware required.

## STEP 18:





## STEP 19:




Hardware required.

## STEP 20:



Hardware required.  
Screwdriver not included


## STEP 21:



Mx4	Nx8	Px2	Qx2	Xx1

Hardware required.  
Screwdriver not included


## STEP 22:




Vx2

Hardware required.


## STEP 23:




## STEP 24:



## STEP 25:




## STEP 26:



Hx20	lx20	Xx1

Hardware required.  
Screwdriver not included

## STEP 27:



**Assembly is complete. The Sideboard is ready to enjoy now !**