













Thank you for purchasing the **MODWAY Vanity!**
Before you start, here are some helpful advice:


- 1.We suggest you spend a short time reading through this leaflet and then follow the simple step-by-step instructions.
- 2.Owing to the size and weight of the vanity, we recommend that it is assembled by two adults, on a carpeted or padded area, in the room that it is intended for. Approximate assembly time: 60 minutes.
- 3.Please do not use any tools other than those provide or recommended in these instructions.
- 4.Please do not throw away any of the packaging or instructions until you have checked all the components and hardware and the furniture is fully assembled.
- 5.Assemble all components loosely until advised to tighten. Depending on use, it may be necessary to tighten the components from time to time, so please save the tools that have been provided.
- 6.Please keep all pieces out of reach of children.



Hardware :

<div>A) Dowel/Wood</div> <div></div> <div>M8 x 25 mm x 32</div>	<div>B) Cambolt/Metal</div> <div></div> <div>Ø6 x 24 mm x 24</div>	<div>C) Camlock/Metal</div> <div></div> <div>Ø15 mm x 24</div>	<div>D) Knob/Metal</div> <div></div> <div>Ø30 mm x 2</div>	<div>E) Screw/Metal</div> <div></div> <div>M4 x 25 mm x 2</div>
<div>F) Screw/Metal</div> <div></div> <div>M4 x 14 mm x 40</div>	<div>G) Hinges/Metal</div> <div></div> <div> x 4</div>	<div>H) Shelf pin/Metal</div> <div></div> <div>Ø5 mm x 4</div>	<div>I) Bracket/Metal</div> <div></div> <div>28 x 100 mm x 4</div>	<div>J) x 1</div> <div></div> <div>Hammer (Not include)</div>
<div>K) x 1</div> <div></div> <div>Screwdriver (Not include)</div>				

Components:




All parts/components are labeled with numbering as the part list below.

① Side Panel Left	x1	② Side Panel Right	x1	③ Bottom Panel	x1	④ Back Panel 1	x1
⑤ Back Panel 2	x1	⑥ Door Left	x1	⑦ Door Right	x1	⑧ Base Panel 1	x1
⑨ Base Panel 2	x1	⑩ Base Panel 3	x2	⑪ Adjustable Shelf	x1	⑫ Vertical Panel 1	x1
⑬ Vertical Panel 2	x1	⑭ Vertical Panel 3	x1	⑮ Vertical Panel 4	x1		

STEP 1 :

Carefully insert the **Wood Dowels (A)** at the designated holes on the relevant parts.




Ax32	Jx1

Hardware required. Hammer not included

STEP 2 : (Power tool not recommended)

Use Philips screwdriver to insert the **Cambolt (B)** carefully at the designated holes on the relevant parts. Please ensure the Cambolt is inserted and secured at the correct pre-drilled holes.




Bx24	Kx1

Hardware required. Screwdriver not included

STEP 3 :

Assemble 2 pieces of **Door Hinges (G)** to the '**Door Left (6)**' and '**Door Right (7)**' on each sides and secure it with 2 pieces of **Screws (F)** for each hinges.




		
Fx8	Gx4	Kx1



Hardware required. Screwdriver not included

STEP 4 :

Properly insert the **Camlock (C)** in the pre-drilled hole then align it to the assembled **Cambolt (B)** to secure both **Back Panel 1 (4)** and **Back Panel 2 (5)** to the **Vertical Panel 3 (14)** and **Vertical Panel 4 (15)**.

This assembly namely **Back Frame Assembly**




	
Cx4	Kx1

Hardware required. Screwdriver not included

STEP 5 :

- 5.1- Lay flat the **Side Panel Left (1)** which already assembled with 8 pieces of **Wood Dowel (A)** and 2 pieces of **Cambolt (B)**.
- 5.2- Properly align the **Bottom Panel (3) Wooden Dowels** to the pre-drilled hole.
- 5.3- Once aligned push the **Bottom Panel (3)** in and align the **Camlocks (C)** to the **Cambolt (B)** to secure the **Bottom Panel (3)** to the **Side Panel Left (1)**.




Cx2	Kx1

Hardware required. Screwdriver not included

STEP 6 :

- 6.1- Lay flat the **Side Panel Right (2)** which already assembled with 8 pieces of **Wood Dowel (A)** and 2 pieces of **Cambolt (B)**.


Repeat step 5.2 - 5.3 to secure the **Side Panel Right (2)** to the **Bottom Panel (3)**.





Cx2	Kx1

STEP 7 :

Properly insert the **Camlock (C)** in the pre-drilled hole then align it to the assembled **Cambolt (B)** to secure both of **Side Panel Left (1)** and **Side Panel Right (2)** to the **Vertical Panel 3 (14)** and **Vertical Panel 4 (15)**.






	
Cx4	Kx1

Hardware required. Screwdriver not included

STEP 8 :

Properly insert the **Camlock (C)** in the pre-drilled hole then align it to the assembled **Cambolt (B)** to secure **Base Panel 3 (10)** to the **Vertical Panel 3 (14)** and **Vertical Panel 4 (15)**.




	
Cx2	Kx1



Hardware required. Screwdriver not included

STEP 9 :

Properly insert the **Camlock (C)** in the pre-drilled hole then align it to the assembled **Cambolt (B)** to secure both **Base Panel 1 (8)** and **Base Panel 2 (9)** to the **Vertical Panel 1 (12)** and **Vertical Panel 2 (13)**.

This assembly namely **Front Frame Assembly**






	
Cx4	Kx1

Hardware required. Screwdriver not included

STEP 10 :

Properly insert the **Camlock (C)** in the pre-drilled hole then align it to the assembled **Cambolt (B)** to secure both of **Side Panel Left (1)** and **Side Panel Right (2)** to the **Vertical Panel 1 (12)** and **Vertical Panel 2 (13)**.





	
Cx6	Kx1

Hardware required. Screwdriver not included


STEP 11 :

Insert the **Shelf Pin (H)** to the pre-drilled holes.



STEP 12 :


Insert **Adjustable Shelf (11)** above the **Shelf Pin (H)**.




STEP 13 :

Hinges Adjustment Facilities


A.Lateral adjustment by screw adjusting






B.Vertical adjustment via slot in the mounting plate



C.Front-to-Back by slacking the hinges arm mounting screw









	
Fx16	Kx1

Hardware required. Screwdriver not included

STEP 14 :

Assemble **Door Knob (D)** on each '**Door Left (6)**' & '**Door Right (7)**' and secure it with a **Screw (E)** by using screwdriver.



		
Dx2	Ex2	Kx1

Hardware required. Screwdriver not included

Hardware required. Screwdriver not included


352mm

Hole=Ø6mm

Screw and Wall Plug are not provided.
Please use appropriate fixtures for you

Screw and Wall Plug are not provided.
Please use appropriate fixtures for your wall.

STEP 17 :



Assembly is complete.

STEP 18 :

Apply a thin bead of silicone compound around the vanity base and set the vanity top carefully in place. Remove any excess silicone compound with a wet rag.

